



*The Hot Gas By-pass Valve need to adjusted.*



*Turn the valve clockwise slowly with the 8mm hex key wrench until the E.V.TEMP shows the pressure 38psi~42psi.*

*E.V.TEMP rang:38psi~42psi*



*E.V.TEMP*

